Technical drawings - Geometrical tolerancing - Toleranced characteristics and symbols - Examples of indication and interpretation

Extract from International Standard

1101

This document forms an extract of ISO 1101, suitable for everyday use.

Form tolerances limit the deviations of an individual feature from its ideal geometrical form.

Orientation, location and run-out tolerances limit the deviations of the mutual orientation and/or location of two or more features. For functional reasons one or more features may be indicated as a datum. If necessary, a geometrical tolerance should be specified to the datum feature in order to ensure that the datum feature is sufficiently exact for its purpose.

Total run-out

The geometrical tolerance applies always to the whole extent of the toleranced feature unless otherwise specified, for example 0,02/50 indicates that a tolerance of 0,02 is permitted for an extent of 50 at any place on the toleranced feature.

When a geometrical tolerance applies to an axis or a median plane, then the arrow of the leader line terminates at the dimension line (figure 4).


When a geometrical tolerance applies to a line or surface itself, then the leader line with its arrow terminating on the contour of the feature has to be clearly separated from the dimension line (figure 5).

> any point on the specified surface during several revolutions about the datum axis A-B, and with relative axial

> movement between part and measuring instrument. The movement shall be guided along a line having a theoretically perfect form of the contour and being in

correct position to the datum axis.

The same method of indication is used for the datum triangle.



8